



RVS 5000H

Rotary valve separator





Spare parts list - sales no. 121102013, 121102015, 121102016 &
121102813, 121102815, 121102816







	Pos.	Spare parts list - page	Notes
1	1	121102913-04-05	RVS 5000 Bottom
1	2	121102913-06-07	RVS 5000 Rotor
1	3	121102913-08-09	RVS 5000 Top
1	4	121102913-10-11	RVS 5000 Motor


121102913-02-03 Revision 01





Pos.	Pcs.	Part no.	Description
1	1	121102200	Bottom for separator
2	2	100401104	Main bearing Ø40
3	4	100304036	Set screw M12x50 DIN 933
4	10	100331007	Washer M12 DIN 125 A
5	8	100316005	Lock nut M12 DIN 985-6
6	2	100323430	Eye bolt M12x80 DIN 444 A 4,6
7	2	100331101	Washer M12 BN 737
8	4	100315016	Nut M12 DIN 934
9	4	100306046	M12x50 DIN931
10	1	121102600	Bracket for plastic edge
11	8	100321047	M6x20 DIN 7991
12	8	100316002	M6 DIN 985-6
13	6	100308058	M8x55 DIN 933
14	6	100331005	Washer 5/16"
15	6	100315012	Nut M8 DIN 934
16	5	100306015	M8x20 DIN 933
17	5	100331096	Washer M8 (8,4-20-2) elgv
18	2	100306058	M16x60 DIN931
19	6	100331008	Washer 5/8"
20	2	100316006	Lock nut M16 DIN 985-6
21	2	121102434	End sieve
22	8	100323439	Flange set screw M10x20 DIN 6921
23	12	100316099	M10 Flange nut
24	2	121104637	Spacer 0,63 mm for RVS 5000-10000
25	2	121104638	Spacer 1,0 mm for RVS 5000-10000
26	2	121104639	Spacer 1,25 mm for RVS 5000-10000
27	2	100414069	Plastic plug Ø44,4/47,7x19mm
28	2	121102529	Sliding damper
29	4	100323438	M10x25 DIN 6921
30	1	121102624	Service Kit RVS 5000



Pos.	Pcs.	Part no.	Description
1	1	121102333	Shaft for RVS 5000
2	7	121102306	Showel plate
3	2	121104944	Hub for 40mm shaft
4	14	121102338	Locking bracket for rotor
5	14	121104950	Locking plate for rotor
6	14	121104959	Locking bracket for rotor
7	14	100306189	M10x80 DIN 931 10.9
8	54	121102337	Bushing for rubber paddle
9	7	121102318	Clamping rail for rubber paddle
10	2	100405042	KEY A12x8x70 DIN 6885
11	2	121102300	End disc for rotor
12	56	100316104	Welding nut M8x10
13	56	100309042	M8x16 with Tuflock DIN 7991
14	63	100316098	Flange nut without teeth M8 DIN6923 elgv
15	54	100323442	M8x25 with Tuflock DIN 6921
16	1	121102297	Scraper for sieve RVS 5000
17	9	121102339	Bushing for rubber paddle and scraper
18	9	100323443	M8x30 with Tuflock DIN 6921
19	2	121102288	Ring for hub
20	14	100306157	M10x70 DIN 931
21	14	100315013	M10 DIN 934
22	1	121102340	Service kit for rotor (14 sealing segments) RVS 5000
23	1	121102618	Service kit for rotor (7 x rubber paddles and 1 x scraper) RVS 5000
24	1	121102621	Service kit for rotor (7 x rubber paddles and 7 x scrapers) RVS 5000



Pos.	Pcs.	Part no.	Description
1	2	121102536	Hinge plate
2	1	121102550	Cover RVS 5000
3	3	121104492	Holder bracket for lock
4	6	121104493	Lock for cover
5	6	100311032	Carriage bolt M10x35 DIN 603
6	6	100414039	Star handle 1512-50 M10
7	6	100306036	Set Screw M10x60 DIN 931
8	18	100331006	Washer M10 DIN 125 A
9	6	100316004	Lock nut M10 DIN 985-6
10	1	121102556	Sealing for hatch
11	12	100308056	Flange set screw M12x50 DIN 6921 elgv
12	24	100315016	Nut M12 DIN 934
13	2	121104398	Lifting eye
14	2	131081423	Label "Lifting point", black on yellow
15	10	100306043	Set screw M12x30 DIN 933
16	10	100331007	Washer M12 DIN 125 A
17	2	121102894	Label "RVS 5000H"
18	2	121000325	Transfer "Arrow"
19	1	121165449	Label "Read user manual", black/red on yellow
20	1	121109322	Label "Risk of cutting / stop", black/red on yellow
21	1	121109324	Label "Risk of cutting", black/red on yellow
22	1	121102562	Sealing top-bottom RVS 5000
23	10	100316103	M12 DIN 6926 elgv
24	1	121102530	Bracket for plastic plugs
25	2	100323380	M8x20 DIN 6921
26	2	100316003	M8 DIN 985-6
27	1	121102210	Top S3 RVS 5000



Pos.	Pcs.	Part no.	Description
1	1	121102233	Moment arm welded RVS 5000
2	1	100505230	Gearmotor 13rpm 1,1kW 3x230/400V 50Hz IE3 CE
3	6	100308207	Flange set screw M12x30 DIN 6921 NV16
4	1	121000325	Label "Arrow", black on white
5	1	121102634	Tool for turning gear RVS 5000 and RVS 10000
6	1	100323381	Flange set screw M8x25 DIN 6921
7	1	100316091	Flange nut M8 with serration DIN9623
8	4	121102692	Rubber washer for vibration damper
9	1	121102698	Washer for vibration damper
10	2	100331007	Washer M12 DIN 125 A
11	1	100306052	M12x100 DIN931
12	1	100316005	Lock nut M12 DIN 985-6
13	1	100505231	Gearmotor 16rpm 1,1kW 3x460V 60Hz IE3 UL/CSA
14	1	121000325	Label "Arrow", black on white
15	1	100505232	Gearmotor 16rpm 1,1kW 3x575V 60Hz IE3 UL/CSA
16	1	121000325	Label "Arrow", black on white
17	1	100505240	Gearmotor 13rpm 1,1kW 3x230/400V 50Hz IE3 CE
18	1	121000325	Label "Arrow", black on white
19	1	100505241	Gearmotor 16rpm 1,1kW 3x460V 60Hz IE3 UL/CSA
20	1	121000325	Label "Arrow", black on white
21	1	100505242	Gearmotor 16rpm 1,1kW 3x575V 60Hz IE3 UL/CSA
22	1	121000325	Label "Arrow", black on white
23	1	121102631	Tool for turning gear RVS 5000 and RVS 10000
24	1	121102634	Tool for turning gear RVS 5000 and RVS 10000

Kongskilde Industries A/S

Skælskørvej 64

DK - 4180 Sorø

Tel. +45 72 17 60 00

mail@kongskilde-industries.com

www.kongskilde-industries.com